


Accessories for microspray / spray nozzles

| Name | Item number |
|---|--------------|
| Accelerator nozzle on mounting block | 30 001 46 00 |
| Accelerator nozzle w/ check valve on mounting block | 30 001 46RVM |



Description:

Universally applicable round nozzle.

Via the adjustment of spray air and medium flow rate of the pump by means of this nozzle a very precise and reproducible spray pattern can be set. Even with little spray air the output of the cooling medium / lubricant in a homogeneous "droplet air mixture" is possible while avoiding unwanted fogging.

For spraying points that are particularly deep in relation to the pump, the accelerator nozzle with integrated check valve (opening pressure approx. 0.4 bar) should be used to prevent the pipe from running empty.

Preferred mounting:

On mounting block, but also applicable in combination with magnetic nozzle holder (30 001 50 01 or ..02).